




Winkelkopf

Angle head


Tête angulaire





Darstellung symbolisch
symbolical drawing
schéma symbolique



Arretierring muss beim
Kunden eingestellt werden
ring has to be adjusted
by customer
la bague d'arrêt doit être
ajustée par le client



Anschluss für optionale
Drehmomentstütze und Abstützung
Connection for optional location device and
optional support device
raccordement pour segment d'arrêt
et support optionnel



Optionen :
options :
options :



Spannzangen
collets
les pinces



Gewindebohrzangen
tapping collets
pinces de taraudage



Wechseleinsatz u-tec
insert u-tec
insert u-tec



Bedienschlüsselsatz
set of wrench
jeu de clés

» weitere Ausführungen auf Anfrage
other models on request
autres modèles sur demande
subject to technical changes

i = 1:1
M₂ max. [Nm] = 25
n₂ max. [min⁻¹] = 8000

Bestell - Nr.
ref.no. / No.de cde.

7 033 44 017