


Mehrfach-Bohrstangenhalter

Multiple boring bar holder


Porte-foret à usage multiple



Darstellung symbolisch
symbolical drawing
schéma symbolique




bei externer Kühlmittelzufuhr Schraube entfernen
for external coolant supply, take off screw
pour arrosage externe, enlevez la vis



Umstellung von IK auf EK

changeover from internal coolant
to external coolant
changement de l'arrosage interne à l'arrosage externe



Optionen :
options :
options :



Bedienschlüssel
wrench
clé

Bestell - Nr.

ref.no. / No.de cde.

8 253 27 015

Technische Änderung vorbehalten

nous nous réservons toutes modifications techniques